

Thermo Scientific pDR-1500 personal DataRAM

Active, real-time aerosol
monitor/data logger with aerodynamic sizing

The Thermo Scientific™ pDR-1500 personal DataRAM was developed to meet the need for a fully integrated, active sampling personal scale instrument with greater accuracy, increased capabilities, low size and weight, maximum ease-of-use and increased operating time.

- True volumetric flow control
Interchangeable cyclones for higher
- Accuracy cut points Personal aerosol instrument with benchtop performance
- Full compensation for environmental variables
- Suitable for NIOSH Methods 0500 and 0600t



The pDR-1500 personal DataRAM is designed for applications such as site remediation, size discrimination, mass validation, exposure modeling, and protection of asthma patients.

The pDR-1500 personal DataRAM accurately measures aerosol concentration in real-time, with relative humidity compensation, true volumetric flow control and legacy pDR nephelometry. An integrated sample filter enables post-gravimetric validation of data.

Superior particle-cut points compared to those achievable using impactors are delivered through volumetric flow control and ACGIH traceable cyclones, available in pairs, for PM₁₀ and PM₄ or PM_{2.5} and PM₁. A toroidal entrance assures optimized aerosol aspiration and a representative sample even without a cyclone.



Thermo
SCIENTIFIC

Thermo Scientific pDR-1500 personal DataRAM

Concentration Measurement Range	0.001 to 400 mg/m ³ range (auto ranging) ¹
Scattered Coefficient Range	1.5 x 10 ⁻⁶ to 0.6 m ⁻¹ (approx) @ lambda= 880nm (not displayed)
Precision/ Repeatability Over 30 days	± 2% of reading or ± 0.005 mg/m ³ , whichever is larger, for 1 second (2-sigma) ² averaging time ± 0.5 of reading or ± 0.0015 mg/m ³ , whichever is larger, for 10 second averaging time ± 0.2% of reading or ± 0.0005 mg/m ³ , whichever is larger, for 60 second averaging time
Accuracy ¹	± 5% of reading ± precision (traceable to SAE Fine Test Dust)
Resolution	0.1% of reading or 0.001 mg/m ³ , whichever is larger
Particle Size Range of Max. Response	0.1 to 10 µm
Flow Rate Range	1.0 to 3.5 liters/minute
Aerodynamic Particle Cut-Point Range	1.0 to 10 µm
Concentration Display Updating Interval	1 second
Concentration Display Averaging Time ³	1 to 60 seconds (user selectable)
Data logging Averaging Periods ³	1 second to 1 hour
Total # of Data Points That Can Be	> 500,000
Number of Data Tags	99 (maximum)
Logged Data	averaging concentration, temperature, RH, barometric pressure, time/date, and data point number
Readout Display	LCD 16 characters (4 mm height) x 2 lines
Serial Interface	USB / RS-232, 19, 200 baud
Computer Requirements	IBM-PC compatible, 486 or higher, Windows 95® or higher, ≥ 8 MB memory, hard disc drive 3.5" floppy, VGA or higher resolution monitor
Real Time Analog Signal	0 to 2V and 4 to 20 mA. Selectable full scale ranges of: 0 - 0.1, 0 - 0.4, 0 -1.0, 0 - 4.0, 0 -10, 0 - 40, 0 -100, and 0 - 400
Internal Battery Run Time	4 AA alkaline, > 24 hr run time, 5 V peak-to-peak @ 1.2 L/min; > 6 hour @ 3.5 L/min
Run Time @ 25° C	Run time may vary with temperature
Current Consumption	70 to 450 mA (in Run Mode); 32 mA (in Ready Mode)
Operation Environment	-10° to 50°C (14° to 122°F), 10 to 95% RH, non-condensing
Storage Environment	-20° to 70°C (-4° to 158°F)
Dimensions (max external)	181 mm (7.1in) H X 143mm (5.6in) W x 84mm (3.3in) D
Weight	1.2kg (41oz)

Notes:

1. Referred to gravimetric calibration with SAE Fine (ISO Fine) test dust (mmd = 2 to 3 µm. g = 2.5, as aerosolized)
2. At constant temperature and full battery voltage
3. User selectable

To maintain optimal product performance, you need immediate access to experts worldwide, as well as priority status when your air quality equipment needs repair or replacement. We offer comprehensive, flexible support solutions for all phases of the product life cycle. Through predictable, fixed-cost pricing, our services help protect the return on investment and total cost of ownership of your Thermo Scientific products.

For more information, visit our website at thermoscientific.com/oeh

© 2012 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries. Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representative for details.

This product is manufactured in a plant whose quality management system is ISO 9001 certified.

USA
27 Forge Parkway
Franklin, MA 02038
Ph: (866) 282-0430
Fax: (508) 520-1460
customerservice.aqi@thermofisher.com

India
C/327, TTC Industrial Area
MIDC Pawane
New Mumbai 400 705, India
Ph: +91 22 4157 8800
india@thermofisher.com

China
+Units 702-715, 7th Floor
Tower West, Yonghe
Beijing, China 100007
+86 10 84193588
info.eid.china@thermofisher.com

Europe
Takkebijsters 1
Breda Netherlands 4801EB
+31 765795641
info.aq.breda@thermofisher.com