


Surveyed

# Advanced Environmental Instrumentation

Harnessing the Power of Mobile Computing







Differential Pressure Meter

PHYR" || MICROMANOMET

GRAYWOLF<sup>®</sup>
SENSING SOLUTIONS
Ph. 1-203-402-0477

EMAIL: SALESTEAM@ GRAYWOLFSENSING.COM

WEBSITE: WWW.GRAYWOLFSENSING.COM

The GrayWolf Zephyr III has exceptional low-end accuracy, yet a wide range.

Auto-ranging ΔP sensors, combined with auto-zeroing make this the top performing handheld micromanometer on the market.

- Differential Pressure accurate to 0.1 Pa, 0.002 inH<sub>2</sub>O (switchable units)
- Broad range ±10,000Pa, ±40 inH<sub>2</sub>O
- The built-in DP sensor module is both autozeroing and auto-ranging for unparalleled true resolution, accuracy and range
- Measure Air Velocity & Volume Flow with the exceptionally accurate (+/- 2% RDG) optional thermal anemometer
- Alternatively, connect Pitot-Static tubes to measure broad-ranging airspeeds, over wide °C/°F ranges

 Display, Trend Log over time or Snap Log instantaneous and/or averaged readings

airspeed probe (shown collapsed)

- Add Audio, Text and other notes to data files on-site
- Generate professional reports with supplied software, automated reports with optional WolfSense® ARG
- On-board educational documents, user tips and video help
- Expand your kit for Pt100 temperature and %RH
- Flexible, powerful, and Easy-To-Use

GRAYWOLF

## ✓ Measure Smart ✓ Report Efficiently

Top View

# ZEPHYR™ III **MICROMANOMETER**

### Differential Pressure Meter

#### SPECIFICATIONS:

General:			
PC Download/Reporting Software Reg's: Windows			
Dimensions:	96.0mm (3.8in.) w. x 177mm (7.0in.) h. x 47.0mm (1.8in) d.		
Construction:	Rugged polycarbonate plastic with rubberized side grips. IP64		
Weight:	700gr (IIb. 8.5oz)		
Screen Size:	785mm (3.5") HVGA 320 x 480 color touch screen with backlight		
Memory:	32GB for data-logging (Imillion+ readings), notes (audio, text, etc.),		
	WS AS application software, help videos, documents and auto data backup		
Mounting:	1/4" - 20 tpi thread (on back) for optional belt clip, mini tripod/stand, etc.		
Operating Ran	ge: -10°C to 50°C (15°F to 122°F), 0 to 100 %RH non-condensing		

2x type-K thermocouple sockets. Range -110° to 2010°F (-80° to 1100°C)

#### Power:

Battery:	4250 mAh Lithium Ion rechargeable
Battery Life:	24+ hours typical for new battery with backlight off
	Battery life will vary when powering external probe
	(AS-201 power consumption increases with air velocity)
Recharge time:	4 hours typical. LED displays charging/fully charged status
Power supply:	100/240VAC, 50-60Hz charger supplied w/US, EU, UK, AU plugs

#### **Built-in Differential Pressure Sensors (included):**

Differential Pressure Range: ±10,000Pa, ±40 inH<sub>2</sub>O, ±1000 mmH<sub>2</sub>O, ±100 mbar, ±70 mmHg

Resolution: 0.1Pa, 0.001 inH<sub>2</sub>O, 0.01 mmH<sub>2</sub>O, 0.001 mbar, 0.001 mmHg

 $\pm 1\%$  of rdg  $\pm 0.1$ Pa up to 250Pa,  $\pm 1\%$ rdg  $\pm 4$ Pa >250Pa Accuracy (auto-zeroing enabled) (±1% of rdg ±0.001 inH2O to 1.000 inH2O,

±1%rdg ±0.015 inH,O>1.000 inH,O)

Differential Pressure is auto-ranging for exceptional low-end detection, yet a broad range. For exceptional accuracy, it is also auto-zeroing (every 2 minutes by default but zeroing frequency is user adjustable to 5 minutes or OFF)

#### RH-AS2 %RH/Temperature Probe (optional):

Relative Humidity Range/Acc: 0 to 100 %RH non-condensing.  $\pm 2\%$ RH <80%RH( $\pm 3\%$ RH>80%RH) 5.0° to 160.0°F (-15° to +70°C) ±0.3°C Air Temperature Range/Accuracy: Dimensions: 2.1" (54mm) L, 0.55" (14mm) Ø

#### AS-201/AS-202 Thermal Anemometer Probes (optional):

Air Velocity Range:	0-6,000 ft/min (0.00-30.00 m/s)	
Accuracy:	±2% of Reading or ±3 ft/min (0.015 m/s), whichever is greater	
Temperature Range:	15° to 160°F (-10° to +70°C)	
Accuracy:	±2° F (1.1°C)	
Stated AS-201/AS-202 temperature accuracy is in a minimum 50 ft/min (0.25 m/s) airflow.		

1.5" (38mm) Ø handle, 7.25" (185mm) L handle, Dimensions:

0.375" (9mm) Ø aerial tip, 0.4375" (11mm) aerial base **AS-201:** 14.9" (380mm) L collapsed, incl. handle, 31.5" (800mm) L extended

AS-202: 21" (530mm) L collapsed, incl. handle & 6" (150mm) tip, 37" (940mm) L extended

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT FURTHER NOTICE

## Optional TC-305S K-type thermocouple surface temperature probe



Optional RH-AS2 probe shown at left with optional ACC-RH-HDLA handle with 1m cable ▼







K-type thermocouple temperature inputs Stylus Mini-USB

High accuracy, extremely low L.O.D., broad range roing and auto-ranging differential pressure ports

- Optional AS-202A articulating, telescoping hotwire air velocity probe
  - ▼ GrayWolf's unique PIT-504-KIT expandable Pitot Tube kit (shown with 2 extra extensions)






GrayWolf's optional 300 Series ▲ K-Type Thermocouple probes (or use your own)

■ PCC-22AS hard-shell case (shown with optional PIT-504-KIT and AS-202)

Optional GrayWolf supplied 30mm, 50mm or 100mm (12",19" or 39") pitot tubes (or use your own) ▼



### **GRAYWOLF®** SENSING SOLUTIONS

6 RESEARCH DRIVE (WORLDWIDE HEADQUARTERS)

SHELTON, CT 06484 USA Рн. (1) 203-402-0477 800-218-7997

EMAIL: SALESTEAM@GRAYWOLFSENSING.COM

WWW.GRAYWOLFSENSING.COM

### **GRAYWOLF** SENSING SOLUTIONS

ANNACOTTY INDUSTRIAL PARK, UNIT 1C ANNACOTTY, COUNTY LIMERICK IRELAND V94 PR2Y PH. (353) 61358044